

T & C -- Version 8.2.1

SETUP = in Diagnostic Program 3 (ARU Signatures).
Refer to Schematic #060-02475.

NOTE: Blue control head should display EOA.

START = RESET U19 pin 9 
STOP = RESET U19 pin 9 
CLOCK = DAB RSTB/ U20 pin 6 
+5V = FP54
GROUND = 0000

U1	1	-	16	FP54
	2	-	15	-
	3	-	14	3U9F
	4	-	13	0000
	5	-	12	0000
	6	-	11	-
	7	FP54	10	40A5
	8	0000	9	FP54

U2	1	0000	24	FP54
	2	07P6	23	45FF
	3	FP4C	22	F344
	4	03UA	21	95CP
	5	3U9U	20	A36H
	6	F5AA	19	3U9F
	7	A0A8	18	0000
	8	53PH	17	0000
	9	028H	16	FP54
	10	-	15	0000
	11	0000	14	0000
	12	0000	13	-

U3	1	07P6	20	FP54
	2	FP4C	19	-
	3	03UA	18	-
	4	3U9U	17	-
	5	F5AA	16	-
	6	A0A8	15	-
	7	53PH	14	-
	8	028H	13	-
	9	FP54	12	-
	10	0000	11	FP54

U4	1	FP54	16	FP54
	2	-	15	-
	3	07P6	14	03U3
	4	FP4C	13	6725
	5	03UA	12	01UH
	6	3U9U	11	1UFU
	7	0000	10	0000
	8	0000	9	0000

U5	1	FP54	16	FP54
	2	-	15	-
	3	F5AA	14	P2H5
	4	A0A8	13	H054
	5	53PH	12	29U6
	6	028H	11	8146
	7	0000	10	0000
	8	0000	9	0000

U10	1	FP54	16	FP54
	2	-	15	-
	3	-	14	-
	4	1UFU	13	8146
	5	H054	12	-
	6	8146	11	F1C3
	7	8146	10	-
	8	0000	9	-

T & C -- Version 8.2.1 (Cont'd.)

U11	1	FP54	16	FP54
	2	-	15	-
	3	-	14	-
	4	01UH	13	29U6
	5	P2H5	12	-
	6	2PU6	11	FPAA
	7	29U6	10	-
	8	0000	9	-

U14	1	-	16	FP54
	2	-	15	-
	3	-	14	45FF
	4	-	13	F344
	5	-	12	95CP
	6	-	11	A36H
	7	FP54	10	FP54
	8	0000	9	FP54

U15	1	0000	24	FP54
	2	C5A9	23	45FF
	3	909P	22	F344
	4	0000	21	95CP
	5	0000	20	A36H
	6	8C99	19	3U9F
	7	UH10	18	0000
	8	0000	17	0000
	9	7302	16	FP54
	10	-	15	0000
	11	0000	14	0000
	12	0000	13	-

U16	1	C5A9	20	FP54
	2	909P	19	-
	3	0000	18	-
	4	0000	17	-
	5	8C99	16	-
	6	0H10	15	-
	7	0000	14	-
	8	7302	13	-
	9	FP54	12	-
	10	0000	11	FP54

U17	1	FP54	16	FP54
	2	-	15	-
	3	C5A9	14	U3AA
	4	909P	13	484U
	5	0000	12	0000
	6	0000	11	0000
	7	0000	10	0000
	8	0000	9	0000

U18	1	FP54	16	FP54
	2	-	15	-
	3	8C99	14	PFC2
	4	0H10	13	2UU6
	5	0000	12	0000
	6	7302	11	3981
	7	0000	10	0000
	8	0000	9	0000

U19	1	-	20	FP54
	2	0000	19	FP54
	3	0000	18	FP54
	4	PFC2	17	6725
	5	PFC2	16	6725
	6	2UU6	15	03U3
	7	2UU6	14	03U3
	8	FP54	13	3981
	9	672A	12	3981
	10	0000	11	-

U20	1	-	16	FP54
	2	-	15	-
	3	-	14	FP54
	4	-	13	-
	5	-	12	-
	6	-	11	-
	7	-	10	FP54
	8	U000	9	9FF0

T & C -- Version 8.2.1 (Cont'd.)

U28	1	FP54	16	FP54
	2	-	15	0000
	3	3U9F	14	-
	4	3U9F	13	-
	5	-	12	-
	6	0000	11	-
	7	0000	10	0000
	8	0000	9	0000

U29	1	0000	24	FP54
	2	4496	23	45FF
	3	P265	22	F344
	4	2P14	21	95CP
	5	F71H	20	A36H
	6	C10H	19	3U9F
	7	A80H	18	0000
	8	CA09	17	0000
	9	909P	16	FP54
	10	-	15	0000
	11	0000	14	0000
	12	0000	13	-

U30	1	4496	20	FP54
	2	P265	19	-
	3	2P14	18	-
	4	F71H	17	-
	5	C10H	16	-
	6	A80H	15	-
	7	CA09	14	-
	8	909P	13	-
	9	FP54	12	-
	10	0000	11	FP54

U31	1	0000	20	FP54
	2	7132	19	A24C
	3	P265	18	4496
	4	F71H	17	2P14
	5	638P	16	970A
	6	H406	15	71U8
	7	A80H	14	C10H
	8	909P	13	CA09
	9	484U	12	HH04
	10	0000	11	-

U32	1	A24C	14	FP54
	2	A24C	13	7132
	3	A24C	12	7132
	4	970A	11	7132
	5	970A	10	638P
	6	970A	9	638P
	7	0000	8	638P

U33	1	-	14	FP54
	2	-	13	-
	3	484U	12	-
	4	861C	11	-
	5	-	10	-
	6	-	9	-
	7	0000	8	-

U34	1	861C	14	FP54
	2	830C	13	3981
	3	0000	12	-
	4	861C	11	-
	5	HH05	10	-
	6	0001	9	U7H5
	7	0000	8	-

U42	1	FP54	16	FP54
	2	-	15	0000
	3	45FF	14	-
	4	45FF	13	A36H
	5	-	12	A36H
	6	F344	11	-
	7	F344	10	95CP
	8	0000	9	95CP

T & C -- Version 8.2.1 (Cont'd.)

U43	1	0000	24	FP54
	2	0616	23	45FF
	3	7P28	22	F344
	4	F237	21	95CP
	5	CA0C	20	A36H
	6	0616	19	3U9F
	7	7P28	18	0000
	8	F184	17	0000
	9	1C45	16	FP54
	10	-	15	0000
	11	0000	14	0000
	12	0000	13	-

U44	1	0616	20	FP54
	2	7P28	19	-
	3	F237	18	-
	4	CA0C	17	-
	5	0616	16	-
	6	7P28	15	-
	7	F184	14	-
	8	1C45	13	-
	9	FP54	12	-
	10	0000	11	FP54

U45	1	0000	20	FP54
	2	3U14	19	830C
	3	7P28	18	0616
	4	CA0C	17	F237
	5	HH05	16	611C
	6	3U14	15	830C
	7	7P28	14	0616
	8	1C45	13	F184
	9	8HA2	12	F9CF
	10	0000	11	-

U46	1	FP54	16	FP54
	2	FP54	15	-
	3	-	14	FP54
	4	FP54	13	-
	5	FP54	12	FP54
	6	FP54	11	FP54
	7	FP54	10	FP54
	8	0000	9	FP54

U47	1	0000	16	FP54
	2	U3AA	15	-
	3	484U	14	71U8
	4	-	13	H406
	5	484U	12	-
	6	U3AA	11	-
	7	CCP5	10	-
	8	0000	9	-

U48	1	U3AA	14	FP54
	2	-	13	-
	3	-	12	6725
	4	861C	11	-
	5	-	10	-
	6	-	9	-
	7	0000	8	-

U49	1	-	14	FP54
	2	861C	13	F9CF
	3	3U14	12	-
	4	861C	11	861C
	5	-	10	FP54
	6	-	9	8HA2
	7	0000	8	55C6

ARU -- Version 8.2.1 -- no feedback

SETUP = Diagnostic Program 3 (ARU Signatures).
Refer to Schematic #060-01318.

NOTE: Blue control head should display EOA.

START = RESET/ extender card pin 16 
STOP = XFERCK U43 pin 11 
CLOCK = ARUCK U10 pin 11 
+5V = 29F3
GROUND = 0000

U2	1	-	14	29F3
	2	-	13	C356
	3	-	12	9A95
	4	-	11	C356
	5	9A95	10	9A95
	6	C356	9	C8P7
	7	0000	8	9124

U3	1	29F3	16	29F3
	2	F494	15	C77H
	3	0000	14	0C0P
	4	0000	13	-
	5	-	12	-
	6	-	11	0000
	7	-	10	8FC4
	8	0000	9	29F3

U4	1	29F3	16	29F3
	2	U69F	15	8575
	3	46PU	14	8653
	4	0000	13	-
	5	-	12	-
	6	-	11	0000
	7	-	10	8FC4
	8	0000	9	29F3

U5	1	3H61	14	29F3
	2	9A95	13	9A95
	3	A7U4	12	P600
	4	9A4H	11	7F95
	5	9A95	10	9A95
	6	00H8	9	5779
	7	0000	8	FHPF

U6	1	91A4	14	29F3
	2	9A95	13	9A95
	3	0C31	12	CU83
	4	HF27	11	2516
	5	9A95	10	9A95
	6	46C2	9	0AU0
	7	0000	8	9065

U7	1	697U	14	29F3
	2	9A95	13	9A95
	3	U3PA	12	PHC1
	4	7U69	11	7724
	5	9A95	10	9A95
	6	P5UF	9	5FF8
	7	0000	8	F65H

U8	1	9A15	14	29F3
	2	9A95	13	9A95
	3	0080	12	4070
	4	H39H	11	HAP5
	5	9A95	10	9A95
	6	4908	9	8441
	7	0000	8	1PH4

U9	1	A175	14	29F3
	2	9A95	13	9A95
	3	3CP0	12	2272
	4	6750	11	C8P7
	5	9A95	10	9A95
	6	UHF5	9	2272
	7	0000	8	C8P7

ARU -- Version 8.2.1 -- no feedback (Cont'd.)

U10	1	0000	20	29F3	U11	1	0000	20	29F3
	2	2272	19	9A15		2	PHC1	19	91A4
	3	3PA1	18	4P6P		3	A127	18	590F
	4	3PA1	17	HH7P		4	F3H4	17	F20A
	5	2272	16	H39H		5	5FF8	16	HF27
	6	6750	15	8441		6	7U69	15	0AU0
	7	C4P4	14	72F6		7	8497	14	6UA4
	8	38AU	13	UAA5		8	A8CC	13	0543
	9	A175	12	4070		9	697U	12	CU83
	10	0000	11	0000		10	0000	11	0000
U12	1	29F3	16	29F3	U13	1	4PHU	16	29F3
	2	P600	15	3H61		2	4CU5	15	8595
	3	-	14	-		3	2FP9	14	78P0
	4	C645	13	0087		4	0087	13	H4C6
	5	H4C6	12	4PHU		5	0097	12	A6FH
	6	-	11	-		6	29H3	11	3F61
	7	5779	10	9A4H		7	29F3	10	C645
	8	0000	9	0000		8	0000	9	2FP9
U14	1	8575	14	29F3	U15	1	29F3	16	29F3
	2	90U2	13	90U2		2	4FF4	15	4FF4
	3	78P0	12	C77H		3	3312	14	0U19
	4	F494	11	2FP9		4	8244	13	57U8
	5	90U2	10	90U2		5	PH68	12	6U15
	6	A6FH	9	8653		6	C156	11	0000
	7	0000	8	0097		7	-	10	8FC4
U16	1	29F3	16	29F3	U17	1	29F3	16	29F3
	2	4FF4	15	4FF4		2	UF7F	15	UCC9
	3	3312	14	35FC		3	3312	14	3PF5
	4	5F3P	13	75F4		4	5F3P	13	A574
	5	AC87	12	UF7F		5	9895	12	F494
	6	U7C9	11	0000		6	F4AC	11	0000
	7	-	10	8FC4		7	-	10	8FC4
	8	0000	9	29F3		8	0000	9	29F3
U18	1	29F3	16	29F3	U19	1	6A6H	16	29F3
	2	6U15	15	F9C1		2	00H8	15	FHPF
	3	75UH	14	0FFH		3	H9P3	14	U0U6
	4	1AH1	13	977F		4	1PU7	13	8P4F
	5	HP7A	12	U69F		5	0A55	12	HUPH
	6	8244	11	0000		6	A7U4	11	7F95
	7	-	10	8FC4		7	C356	10	7A3U
	8	0000	9	29F3		8	0000	9	3P92

ARU -- Version 8.2.1 -- no feedback (Cont'd.)

U20	1	2161	16	29F3	U21	1	HCUP	16	29F3
	2	46C2	15	9065		2	P5UF	15	F65H
	3	5941	14	CA1P		3	5938	14	44PA
	4	7819	13	P813		4	94F5	13	CA12
	5	4HCA	12	6HA3		5	A547	12	9152
	6	0C31	11	2516		6	U3PA	11	7724
	7	3P92	10	8AHH		7	F268	10	HPH3
	8	0000	9	F268		8	0000	9	38A5
U22	1	6P49	16	29F3	U23	1	F2A5	16	29F3
	2	4908	15	1PH4		2	UHF5	15	C8P7
	3	1UP4	14	7H7H		3	07F5	14	H491
	4	313U	13	5C0F		4	97CF	13	54H3
	5	091A	12	85A6		5	94U9	12	H491
	6	0080	11	HAP5		6	3CP0	11	C8P7
	7	38A5	10	67P6		7	38A5	10	54H3
	8	0000	9	38A5		8	0000	9	-
U24	1	C4P4	16	29F3	U25	1	8497	16	29F3
	2	0CHA	15	819U		2	3P83	15	2HF9
	3	9PP9	14	9PP9		3	9CF3	14	FUFA
	4	38AU	13	3PA1		4	A8CC	13	F3H4
	5	9321	12	9PP9		5	4380	12	11P7
	6	8767	11	819U		6	8777	11	943H
	7	2FP9	10	3PA1		7	6F4F	10	A127
	8	0000	9	-		8	0000	9	24UH
U26	1	F9C1	14	29F3	U27	1	OFFH	14	29F3
	2	90U2	13	90U2		2	4471	13	4471
	3	FUFA	12	UCC9		3	3P83	12	F9C1
	4	OFFH	11	9CF3		4	UCC9	11	943H
	5	90U2	10	90U2		5	4471	10	4471
	6	4380	9	UF7F		6	2HF9	9	3PF5
	7	0000	8	11P7		7	0000	8	8777
U28	1	8575	14	29F3	U29	1	-	16	29F3
	2	4471	13	4471		2	-	15	-
	3	3F61	12	0C0P		3	-	14	29F3
	4	8653	11	29H3		4	U7C9	13	29F3
	5	4471	10	4471		5	AC87	12	29F3
	6	4CU5	9	C77H		6	PH68	11	0000
	7	0000	8	8595		7	5F3P	10	3312
						8	0000	9	8244

ARU -- Version 8.2.1 -- no feedback (Cont'd.)

U30	1	-	16	29F3	U31	1	-	16	29F3
	2	-	15	-		2	-	15	-
	3	-	14	29F3		3	-	14	29F3
	4	U7C9	13	29F3		4	U7C9	13	29F3
	5	AC87	12	29F3		5	AC87	12	29F3
	6	75UH	11	0000		6	HP7A	11	0000
	7	U7C9	10	AC87		7	5F3P	10	3312
	8	0000	9	C156		8	0000	9	1AH1
U32	1	-	16	29F3	U33	1	0000	16	29F3
	2	-	15	-		2	1PU7	15	0000
	3	-	14	29F3		3	9124	14	7A3U
	4	U7C9	13	29F3		4	1PU7	13	9124
	5	AC87	12	29F3		5	6A6H	12	7A3U
	6	46PU	11	0000		6	9124	11	8P4F
	7	F4AC	10	9895		7	6A6H	10	9124
	8	0000	9	8244		8	0000	9	8P4F
U34	1	0000	16	29F3	U35	1	0000	16	29F3
	2	7819	15	0000		2	94F5	15	0000
	3	9124	14	8AHH		3	9124	14	HPH3
	4	7819	13	9124		4	94F5	13	9124
	5	2161	12	8AHH		5	HCUP	12	HPH3
	6	9124	11	P813		6	9124	11	CA12
	7	2161	10	9124		7	HCUP	10	9124
	8	0000	9	P813		8	0000	9	CA12
U36	1	0000	16	29F3	U37	1	0000	16	29F3
	2	313U	15	0000		2	97CF	15	0000
	3	9124	14	67P6		3	9124	14	54H3
	4	313U	13	9124		4	97CF	13	C8P7
	5	6P49	12	67P6		5	F2A5	12	54H3
	6	9124	11	5C0F		6	9124	11	54H3
	7	6P49	10	9124		7	F2A5	10	C8P7
	8	0000	9	5C0F		8	0000	9	54H3
U38	1	HH7P	16	29F3	U39	1	F20A	16	29F3
	2	968C	15	2H9U		2	3PH5	15	F772
	3	2A87	14	3P2C		3	95C9	14	F1CU
	4	4P6P	13	72F6		4	590F	13	6UA4
	5	45PP	12	1789		5	U2F4	12	1789
	6	2U7H	11	8160		6	8721	11	7P86
	7	24UH	10	UAA5		7	2FP9	10	0543
	8	0000	9	2FP9		8	0000	9	6F4F

ARU -- Version 8.2.1 -- no feedback (Cont'd.)

U40	1	U69F	14	29F3
	2	4471	13	4471
	3	3PH5	12	A574
	4	977F	11	F772
	5	4471	10	4471
	6	7P86	9	F494
	7	0000	8	8721

U41	1	977F	14	29F3
	2	90U2	13	90U2
	3	F1C0	12	A574
	4	3PF5	11	95C9
	5	90U2	10	90U2
	6	1789	9	U69F
	7	0000	8	U2F4

U42	1	54H3	14	29F3
	2	54H3	13	-
	3	0000	12	-
	4	-	11	-
	5	-	10	29F3
	6	-	9	29F3
	7	0000	8	0000

U43	1	2839	20	29F3
	2	-	19	-
	3	97CF	18	6P49
	4	67P6	17	5C0F
	5	-	16	-
	6	-	15	-
	7	54H3	14	HPH3
	8	F2A5	13	313U
	9	-	12	-
	10	0000	11	-

U44	1	2839	20	29F3
	2	-	19	-
	3	94F5	18	2161
	4	8AHH	17	P813
	5	-	16	-
	6	-	15	-
	7	CA12	14	7A3U
	8	HCUP	13	7819
	9	-	12	-
	10	0000	11	-

U45	1	3108	16	29F3
	2	0000	15	-
	3	7A3U	14	HUPH
	4	8P4F	13	U0U6
	5	6A6H	12	H9P3
	6	1PU7	11	0A55
	7	0000	10	0000
	8	0000	9	0000

U46	1	3108	16	29F3
	2	0000	15	-
	3	8AHH	14	6HA3
	4	P813	13	CA1P
	5	2161	12	5941
	6	7819	11	4HCA
	7	0000	10	0000
	8	0000	9	0000

U47	1	3108	16	29F3
	2	0000	15	-
	3	HPH3	14	9152
	4	CA12	13	44PA
	5	HCUP	12	5938
	6	94F5	11	A547
	7	0000	10	0000
	8	0000	9	0000

U48	1	3108	16	29F3
	2	0000	15	-
	3	67P6	14	85A6
	4	5C0F	13	7H7H
	5	6P49	12	1UP4
	6	313U	11	091A
	7	0000	10	0000
	8	0000	9	0000

U49	1	3108	16	29F3
	2	0000	15	-
	3	54H3	14	H491
	4	54H3	13	H491
	5	F2A5	12	07F5
	6	97CF	11	94U9
	7	0000	10	0000
	8	0000	9	0000

ARU — Version 8.2.1 -- no feedback (Cont'd.)

U50	1	UF7F	14	29F3
	2	4471	13	4471
	3	2U7H	12	57U8
	4	6U15	11	8160
	5	4471	10	4471
	6	968C	9	75F4
	7	0000	8	2H9U

U51	1	6U15	14	29F3
	2	90U2	13	90U2
	3	45PP	12	33FC
	4	75F4	11	1789
	5	90U2	10	90U2
	6	2A87	9	57U8
	7	0000	8	3P2C

U52	1	0U19	14	29F3
	2	4471	13	4471
	3	0CHA	12	35FC
	4	4FF4	11	8767
	5	4471	10	4471
	6	819U	9	4FF4
	7	0000	8	819U

U53	1	0U19	14	29F3
	2	90U2	13	90U2
	3	9321	12	4FF4
	4	4FF4	11	9PP9
	5	90U2	10	90U2
	6	9PP9	9	4FF4
	7	0000	8	9PP9

U54	1	HP7A	14	29F3
	2	U7C9	13	C931
	3	0000	12	90U2
	4	29F3	11	6HC2
	5	8244	10	4471
	6	AC87	9	0000
	7	0000	8	29F3

ARU -- Version 8.2.1

SETUP = Diagnostic Program 3 (ARU Signatures).
Refer to Schematic #060-01318.

NOTE: Blue control head should display EOA.

START = RESET/ extender card pin 16
STOP = RESET/ extender card pin 16
CLOCK = ARUCK U10 pin 11
+5V = 3696
GROUND = 0000



U2	1	-	14	3696
	2	-	13	U804
	3	-	12	FP92
	4	-	11	U804
	5	FP92	10	FP92
	6	U804	9	3P2U
	7	0000	8	08C9

U3	1	3696	16	3696
	2	9C33	15	8P47
	3	0000	14	U8A9
	4	0000	13	-
	5	-	12	-
	6	-	11	0000
	7	-	10	4573
	8	0000	9	3696

U4	1	3696	16	3696
	2	343H	15	2149
	3	50U5	14	5465
	4	0000	13	-
	5	-	12	-
	6	-	11	0000
	7	-	10	4573
	8	0000	9	3696

U5	1	85U0	14	3696
	2	FP92	13	FP92
	3	4C62	12	HFUF
	4	H10A	11	126P
	5	FP92	10	FP92
	6	1U98	9	0HP6
	7	0000	8	F374

U6	1	H827	14	3696
	2	FP92	13	FP92
	3	16C5	12	5C3U
	4	876U	11	95AH
	5	FP92	10	FP92
	6	49UH	9	162P
	7	0000	8	H8CF

U7	1	4808	14	3696
	2	FP92	13	FP92
	3	869A	12	3A87
	4	UP8C	11	U415
	5	FP92	10	FP92
	6	3019	9	FCFH
	7	0000	8	055U

U8	1	361P	14	3696
	2	FP92	13	FP92
	3	U88F	12	H021
	4	A1P2	11	1PC3
	5	FP92	10	FP92
	6	6U70	9	3077
	7	0000	8	UPP5

U9	1	C7C3	14	3696
	2	FP92	13	FP92
	3	7921	12	U0CH
	4	6U12	11	3P2U
	5	FP92	10	FP92
	6	A180	9	U0CH
	7	0000	8	3P2U

ARU -- Version 8.2.1 (Cont'd.)

U10	1	0000	20	3696
	2	U0CH	19	361P
	3	CAF1	18	3786
	4	CAF1	17	187U
	5	U0CH	16	A1P2
	6	6U12	15	3077
	7	859P	14	3C55
	8	34HF	13	UCU9
	9	C7C3	12	H021
	10	0000	11	0000

U11	1	0000	20	3696
	2	3A87	19	H827
	3	2PC5	18	PCU4
	4	FF20	17	5565
	5	FCFH	16	876U
	6	UP8C	15	162P
	7	A6AF	14	77P6
	8	FCAC	13	PHF4
	9	4808	12	5C3U
	10	0000	11	0000

U12	1	3696	16	3696
	2	HFUF	15	85U0
	3	-	14	-
	4	P243	13	505C
	5	4077	12	U9AP
	6	-	11	-
	7	0HP6	10	H10A
	8	0000	9	0000

U13	1	U9AP	16	3696
	2	U903	15	6FF1
	3	1P6H	14	3276
	4	505C	13	4077
	5	33UP	12	3P50
	6	5533	11	F27P
	7	3696	10	P243
	8	0000	9	1P6H

U14	1	2149	14	3696
	2	86CP	13	86CP
	3	3276	12	8P47
	4	9C33	11	1P6H
	5	86CP	10	86CP
	6	3P50	9	5465
	7	0000	8	33UP

U15	1	3696	16	3696
	2	0UAH	15	0UAH
	3	3PC5	14	5140
	4	UH8F	13	HU4H
	5	9CPU	12	2C67
	6	F339	11	0000
	7	-	10	4573
	8	0000	9	3696

U16	1	3696	16	3696
	2	0UAH	15	0UAH
	3	3PC5	14	APH6
	4	58H6	13	2344
	5	FC1A	12	UC7F
	6	93FF	11	0000
	7	-	10	4573
	8	0000	9	3696

U17	1	3696	16	3696
	2	UC7F	15	81PA
	3	3PC5	14	567U
	4	58H6	13	9FFP
	5	U5AU	12	9C33
	6	AH79	11	0000
	7	-	10	4573
	8	0000	9	3696

U18	1	3696	16	3696
	2	2C67	15	2PP4
	3	6P40	14	U971
	4	0823	13	33F0
	5	A55A	12	343H
	6	UH8F	11	0000
	7	-	10	4573
	8	0000	9	3696

U19	1	2A65	16	3696
	2	1U98	15	F374
	3	60CU	14	09U9
	4	P885	13	9AH7
	5	5CP3	12	34P3
	6	4C62	11	126P
	7	U804	10	F5F1
	8	0000	9	F7P1

ARU -- Version 8.2.1 (Cont'd.)

U20	1	U9U2	16	3696
	2	49UH	15	H8CF
	3	4815	14	6A06
	4	9136	13	P978
	5	4062	12	011F
	6	16C5	11	95AH
	7	F7P1	10	U058
	8	0000	9	440C

U21	1	PHPF	16	3696
	2	3019	15	055U
	3	0H92	14	8U4F
	4	PC08	13	P9P4
	5	2999	12	CA59
	6	869A	11	U415
	7	440C	10	12U0
	8	0000	9	5F4F

U22	1	411A	16	3696
	2	6U70	15	UPP5
	3	4U40	14	2U18
	4	CHH8	13	C5PH
	5	1918	12	1126
	6	U88F	11	1PC3
	7	5F4F	10	5064
	8	0000	9	UA22

U23	1	6665	16	3696
	2	A180	15	3P2U
	3	4FF8	14	P1UC
	4	0HH7	13	77AH
	5	8PH4	12	P1UC
	6	7921	11	3P2U
	7	UA22	10	77A3
	8	0000	9	-

U24	1	859P	16	3696
	2	6P1P	15	5141
	3	P500	14	P500
	4	34HF	13	CAF1
	5	PU81	12	P500
	6	809C	11	5141
	7	5CF6	10	CAF1
	8	0000	9	-

U25	1	A6AF	16	3696
	2	4H81	15	0C16
	3	FHUC	14	P1P0
	4	FCAC	13	FF20
	5	C6PH	12	AH67
	6	P33P	11	A5A9
	7	9P78	10	2PC5
	8	0000	9	267C

U26	1	2PP4	14	3696
	2	86CP	13	86CP
	3	P1P0	12	81PA
	4	U971	11	FHUC
	5	86CP	10	86CP
	6	C6PH	9	UC7F
	7	0000	8	AH67

U27	1	U971	14	3696
	2	0205	13	0205
	3	4H81	12	2PP4
	4	81PA	11	A5A9
	5	0205	10	0205
	6	0C16	9	567U
	7	0000	8	P33P

U28	1	2149	14	3696
	2	0205	13	0205
	3	F27P	12	U8A9
	4	5465	11	5533
	5	0205	10	0205
	6	U903	9	8P47
	7	0000	8	6FF1

U33	1	000P	16	3696
	2	P885	15	0000
	3	08C9	14	F5F1
	4	P885	13	08C9
	5	2A65	12	F5F1
	6	08C9	11	9AH7
	7	2A6H	10	08C9
	8	0000	9	9AHU

ARU -- Version 8.2.1 (Cont'd.)

U34	1	000P	16	3696
	2	9136	15	0000
	3	08C9	14	U058
	4	9136	13	08C9
	5	U9U2	12	U05P
	6	08C9	11	P978
	7	U9U0	10	08C9
	8	0000	9	P978

U36	1	000P	16	3696
	2	CHH8	15	0000
	3	08C9	14	5064
	4	CHHP	13	08C9
	5	411A	12	5062
	6	08C9	11	C5PH
	7	4110	10	08C9
	8	0000	9	C5P9

U38	1	187U	16	3696
	2	9740	15	1A74
	3	29UF	14	82P8
	4	3786	13	3C55
	5	8476	12	C2A0
	6	958C	11	H721
	7	267C	10	UCU9
	8	0000	9	5CF6

U40	1	343H	14	3696
	2	0205	13	0205
	3	496H	12	9FFP
	4	33F0	11	47U5
	5	0205	10	0205
	6	P94A	9	9C33
	7	0000	8	P7H2

U42	1	77A3	14	3696
	2	77AH	13	-
	3	000P	12	-
	4	-	11	-
	5	-	10	3696
	6	-	9	3696
	7	-	8	0000

U35	1	000P	16	3696
	2	PC08	15	0000
	3	08C9	14	12U0
	4	PC02	13	08C9
	5	PHPF	12	12UF
	6	08C9	11	P9P4
	7	PHPA	10	08C9
	8	0000	9	P9PA

U37	1	000P	16	3696
	2	0HH7	15	0000
	3	08C9	14	77A3
	4	0HHH	13	3P2U
	5	6665	12	77A3
	6	08C9	11	77AH
	7	666C	10	3P2U
	8	0000	9	77A3

U39	1	5565	16	3696
	2	496H	15	47U5
	3	F27F	14	PP67
	4	PCU4	13	77P6
	5	124C	12	9AU6
	6	P7H2	11	P94A
	7	1P6H	10	PHF4
	8	0000	9	9P78

U41	1	33F0	14	3696
	2	86CP	13	86CP
	3	PP67	12	9FFP
	4	567U	11	F27F
	5	86CP	10	86CP
	6	9AU6	9	343H
	7	0000	8	124C

U43	1	25C5	20	3696
	2	-	19	-
	3	0HHH	18	4110
	4	5062	17	C5P9
	5	-	16	-
	6	-	15	-
	7	77A3	14	12UF
	8	666C	13	CHHP
	9	-	12	-
	10	0000	11	-

ARU -- Version 8.2.1 (Cont'd.)

U44	1	25C5	20	3696
	2	-	19	-
	3	PC02	18	U9U0
	4	U05P	17	P978
	5	-	16	-
	6	-	15	-
	7	P9PA	14	F5F1
	8	PHPA	13	9136
	9	-	12	-
	10	0000	11	-

U45	1	8658	16	3696
	2	0000	15	-
	3	F5F1	14	34P3
	4	9AHU	13	09U9
	5	2A6H	12	60CU
	6	P885	11	5CP3
	7	0000	10	0000
	8	0000	9	0000

U46	1	8658	16	3696
	2	0000	15	-
	3	U05P	14	011F
	4	P978	13	6A06
	5	U9U0	12	4815
	6	9136	11	4062
	7	0000	10	0000
	8	0000	9	0000

U47	1	8658	16	3696
	2	0000	15	-
	3	12UF	14	CA59
	4	P9PA	13	8U4F
	5	PHPA	12	0H92
	6	PC02	11	2999
	7	0000	10	0000
	8	0000	9	0000

U48	1	8658	16	3696
	2	0000	15	-
	3	5062	14	1126
	4	C5P9	13	2U18
	5	4110	12	4U40
	6	CHHP	11	1918
	7	0000	10	0000
	8	0000	9	0000

U49	1	8658	16	3696
	2	0000	15	-
	3	77A3	14	P1UC
	4	77A3	13	P1UC
	5	666C	12	4FF8
	6	0HHH	11	8PH4
	7	0000	10	0000
	8	0000	9	0000

U50	1	UC7F	14	3696
	2	0205	13	0205
	3	958C	12	HU4H
	4	2C67	11	H721
	5	0205	10	0205
	6	9740	9	2344
	7	0000	8	1A74

U51	1	2C67	14	3696
	2	86CP	13	86CP
	3	8476	12	APH6
	4	2344	11	C2A0
	5	86CP	10	86CP
	6	29UF	9	HU4H
	7	0000	8	82P8

U52	1	5140	14	3696
	2	0205	13	0205
	3	6P1P	12	APH6
	4	0UAH	11	809C
	5	0205	10	0205
	6	5141	9	0UAH
	7	0000	8	5141

U53	1	5140	14	3696
	2	86CP	13	86CP
	3	PU81	12	0UAH
	4	0UAH	11	P500
	5	86CP	10	86CP
	6	P500	9	0UAH
	7	0000	8	P500

ARU -- Version 8.2.1 (Cont'd.)

U54	1	A55A	14	3696
	2	93FF	13	C028
	3	0000	12	86CP
	4	3696	11	3493
	5	UH8F	10	0205
	6	FC1A	9	0000
	7	0000	8	3696

DMEM -- Version 8.2.1

SETUP = Diagnostic Program 3 (ARU Signatures).
 Lift U65 pin 13 and jumper to U65 pin 1.
 Refer to Schematic #060-02512.

NOTE: Blue control head should display EOA.

START = MSB of CPC; U65 pin 8 
 STOP = MSB of CPC; U65 pin 8 
 CLOCK = RESET/ U58A pin 1 
 +5V = 826P
 GROUND = 0000

U1-	1	-	16	0000
U16,	2	-	15	-
U20-	3	-	14	-
U35	4	-	13	0AU1
	5	UH56	12	A6F7
	6	P279	11	FU8U
	7	861U	10	44U7
	8	-	9	-

U17	1	-	16	-
	2	0AU1	15	0AU1
	3	A6F7	14	A6F7
	4	UH56	13	UH56
	5	FU8U	12	FU8U
	6	P279	11	P279
	7	44U7	10	44U7
	8	861U	9	861U

U18	1	0000	16	826P
	2	FU8U	15	0000
	3	1F7P	14	8HU0
	4	FU8U	13	9237
	5	44U7	12	-
	6	6633	11	-
	7	44U7	10	74P1
	8	0000	9	0AU1

U36	1	0000	16	826P
	2	UH56	15	0000
	3	UF4C	14	A6F7
	4	UH56	13	6266
	5	861U	12	A6F7
	6	5439	11	P279
	7	861U	10	440H
	8	0000	9	P279

U48	1	826P	20	826P
	2	826P	19	826P
	3	-	18	-
	4	0000	17	0000
	5	-	16	-
	6	0000	15	0000
	7	-	14	-
	8	0000	13	0000
	9	-	12	-
	10	0000	11	0000

U49	1	5439	16	826P
	2	0000	15	0000
	3	2A1F	14	A206
	4	UF4C	13	440H
	5	7P25	12	C133
	6	0000	11	0000
	7	826P	10	6266
	8	0000	9	9241

U50	1	6633	16	826P
	2	0000	15	826P
	3	3319	14	7C47
	4	1F7P	13	74P1
	5	8P3U	12	C25F
	6	0000	11	0000
	7	9241	10	9237
	8	0000	9	A077

U51	1	-	14	826P
	2	0000	13	C133
	3	7P25	12	0000
	4	2A1F	11	8P3U
	5	A206	10	3319
	6	C133	9	7C47
	7	0000	8	C25F

DMEH -- Version 8.2.1 (Cont'd.)

U62	1	826P	20	826P
	2	0000	19	826P
	3	-	18	-
	4	0000	17	826P
	5	-	16	-
	6	0000	15	0000
	7	-	14	-
	8	0000	13	0000
	9	-	12	-
	10	0000	11	0000

U64	1	44U7	16	826P
	2	0000	15	0000
	3	19H6	14	HP66
	4	FU8U	13	0AU1
	5	5H21	12	U81P
	6	826P	11	0000
	7	10F0	10	8HU0
	8	0000	9	FPHA

U63	1	861U	16	826P
	2	0000	15	0000
	3	19H6	14	HP66
	4	UH56	13	P279
	5	5H21	12	U81P
	6	0000	11	0000
	7	A077	10	A6F7
	8	0000	9	10F0

U65	1	C25F	14	826P
	2	0000	13	C25F
	3	5H21	12	0000
	4	0000	11	5H21
	5	HP66	10	19H6
	6	U81P	9	HP66
	7	0000	8	U81P

FPC -- Version 8.2.1

SETUP = Diagnostic Program 6 (FPC Signatures).

Lift pin 11 of SAR IC (U26) on AIN module and jumper to +5V.

Refer to Schematic #060-01320.

NOTE: Blue control head should display EOF.


START = RESET U4 pin 2

STOP = RESET U4 pin 2

CLOCK = FPCCLK U4 pin 5

+5V = 96F6

GROUND = 0000



U1	1	96F6	16	96F6
	2	0000	15	-
	3	0000	14	1686
	4	96F6	13	388A
	5	0000	12	AP4F
	6	0000	11	-
	7	80F0	10	80F0
	8	0000	9	C869

U2	1	96F6	16	96F6
	2	0000	15	80F0
	3	0000	14	-
	4	96F6	13	H48C
	5	0000	12	-
	6	96F6	11	-
	7	96F6	10	388A
	8	0000	9	C869

U3	1	96F6	16	96F6
	2	-	15	96F6
	3	5151	14	AP4F
	4	0000	13	UC7P
	5	96F6	12	0000
	6	-	11	96F6
	7	-	10	5F99
	8	0000	9	-

U4	1	0000	16	96F6
	2	4C63	15	0000
	3	96F6	14	5151
	4	4C63	13	H30A
	5	0000	12	5151
	6	-	11	96F6
	7	0000	10	H30A
	8	0000	9	96F6

U5	1	AU07	14	96F6
	2	P11U	13	1H0P
	3	-	12	96F6
	4	1C7C	11	-
	5	CHC5	10	-
	6	96F6	9	2712
	7	0000	8	H30A

U6	1	AU07	16	96F6
	2	P11U	15	0000
	3	1H0P	14	0000
	4	1358	13	0000
	5	1C7C	12	38UP
	6	CHC5	11	7FU6
	7	26HC	10	72A7
	8	0000	9	6HU5

U7	1	4C63	16	96F6
	2	0000	15	0000
	3	-	14	1H0P
	4	-	13	P11U
	5	-	12	AU07
	6	-	11	0000
	7	96F6	10	2712
	8	-	9	96F6

U8	1	4C63	16	96F6
	2	0000	15	2712
	3	-	14	1C7C
	4	-	13	CHC5
	5	-	12	26HC
	6	-	11	1358
	7	96F6	10	96F6
	8	-	9	-

FPC -- Version 8.2.1 (Cont'd.)

U12	1	0000	14	96F6	U13	1	-	14	96F6
	2	-	13	1686		2	-	13	-
	3	96F6	12	H48C		3	-	12	-
	4	-	11	UC7P		4	-	11	-
	5	-	10	87H6		5	-	10	1A65
	6	-	9	C869		6	-	9	4325
	7	0000	8	3UCU		7	0000	8	5940
U14	1	-	14	96F6	U15	1	0000	14	96F6
	2	-	13	2PAU		2	-	13	-
	3	C869	12	-		3	5151	12	-
	4	1110	11	388A		4	-	11	1110
	5	HP96	10	-		5	-	10	87H6
	6	5940	9	-		6	-	9	2PAU
	7	0000	8	-		7	0000	8	C869
U16	1	96F6	16	96F6	U17	1	AU07	14	96F6
	2	0000	15	-		2	-	13	P11U
	3	96F6	14	-		3	-	12	77H9
	4	96F6	13	-		4	-	11	-
	5	96F6	12	36UA		5	-	10	-
	6	-	11	-		6	-	9	6HU5
	7	36UA	10	36UA		7	0000	8	UC33
	8	0000	9	UC33					
U18	1	96F6	16	96F6	U23	1	96F6	16	96F6
	2	-	15	3953		2	-	15	1A65
	3	6C8P	14	-		3	428H	14	4325
	4	41HA	13	72A7		4	9U57	13	2U46
	5	38UP	12	7FU6		5	P3A1	12	6211
	6	-	11	A8CH		6	A12F	11	0000
	7	41HA	10	3P7C		7	010H	10	3UCU
	8	0000	9	0000		8	0000	9	2PAU
U24	1	96F6	16	96F6	U25	1	96F6	20	96F6
	2	-	15	010H		2	96F6	19	96F6
	3	HHHA	14	52A5		3	-	18	-
	4	PA30	13	2513		4	96F6	17	96F6
	5	P3A1	12	76CC		5	-	16	-
	6	H44C	11	0000		6	96F6	15	96F6
	7	010H	10	3UCU		7	-	14	-
	8	0000	9	2PAU		8	36UA	13	96F6
						9	-	12	-
						10	0000	11	96F6

FPC -- Version 8.2.1 (Cont'd.)

U26	1	96F6	20	96F6
	2	7C6U	19	96F6
	3	-	18	-
	4	96F6	17	0000
	5	-	16	-
	6	96F6	15	0000
	7	-	14	-
	8	96F6	13	0000
	9	-	12	-
	10	0000	11	HC53

U27	1	96F6	16	96F6
	2	-	15	HC53
	3	AH63	14	0000
	4	AH63	13	0000
	5	AH63	12	0000
	6	AH63	11	0000
	7	7C6U	10	36UA
	8	0000	9	6HU5

U28	1	96F6	16	96F6
	2	-	15	7C6U
	3	AH63	14	96F6
	4	CA1F	13	96F6
	5	735H	12	96F6
	6	0A75	11	0000
	7	96F6	10	36UA
	8	0000	9	6HU5

U34	1	96F6	16	96F6
	2	-	15	010H
	3	HHHA	14	52A5
	4	PA30	13	2513
	5	P3A1	12	76CC
	6	H44C	11	0000
	7	010H	10	3UCU
	8	0000	9	2PAU

U35	1	96F6	16	96F6
	2	-	15	010H
	3	HHHA	14	-
	4	PA30	13	-
	5	P3A1	12	-
	6	H44C	11	0000
	7	-	10	3UCU
	8	0000	9	2PAU

U36	1	5151	20	96F6
	2	HHHA	19	H44C
	3	-	18	-
	4	-	17	-
	5	PA30	16	P3A1
	6	P3A1	15	PA30
	7	-	14	-
	8	-	13	-
	9	H44C	12	HHHA
	10	0000	11	0000

U37	1	5151	20	96F6
	2	428H	19	H44C
	3	-	18	-
	4	-	17	-
	5	9U57	16	P3A1
	6	P3A1	15	PA30
	7	-	14	-
	8	-	13	-
	9	A12F	12	HHHA
	10	0000	11	0000

U38	1	96F6	16	96F6
	2	-	15	96F6
	3	2550	14	96F6
	4	POC4	13	96F6
	5	H808	12	96F6
	6	9U1U	11	0000
	7	96F6	10	36UA
	8	0000	9	6HU5

FPC — Version 8.2.1 (Cont'd.)

U39	1	96F6	16	96F6
	2	-	15	96F6
	3	57UH	14	96F6
	4	2PP1	13	96F6
	5	81F2	12	36UA
	6	9426	11	0000
	7	0000	10	36UA
	8	0000	9	6HU5

U40	1	96F6	16	96F6
	2	0000	15	-
	3	CCC4	14	HHHA
	4	HHHA	13	A12F
	5	3PAP	12	9U57
	6	9U57	11	7567
	7	0000	10	0000
	8	0000	9	5151

U41	1	96F6	16	96F6
	2	0000	15	-
	3	HHHA	14	779C
	4	A12F	13	49P0
	5	9U57	12	6HUP
	6	7567	11	F543
	7	0000	10	0000
	8	0000	9	C869

U42	1	000U	16	96F6
	2	779C	15	5F99
	3	P11U	14	F543
	4	C3U7	13	77H9
	5	49P0	12	43PH
	6	P11U	11	6HUP
	7	3833	10	77H9
	8	0000	9	0276

U43	1	96F6	16	96F6
	2	0000	15	HP96
	3	0000	14	584H
	4	0000	13	9P3F
	5	96F6	12	-
	6	96F6	11	-
	7	1110	10	96F6
	8	0000	9	C869